

AVAILABLE PART IS:
90508GS (GLASS SHADE)

MODEL: 90505
ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

TOOLS

YOU WILL NEED THE FOLLOWING TOOLS AND EQUIPMENT: LADDER, SCREWDRIVER, ADJUSTABLE WRENCH, WIRE CUTTERS, PLIERS.

UNPACK THE FIXTURE

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS IN THE PACKAGE: CANOPY, (2) CHAINS, METAL FRAME, (8) HANGING HOOKS, (2) GLASS SHADES, (2) METAL CAPS AND (2) SOCKET RINGS. TO PROTECT THE FINISH, PLACE ALL PARTS ON A SOFT SURFACE.

MOUNTING HARDWARE PACKAGE:

CROSSBAR, GREEN GROUND SCREW, (2) 3" WOOD SCREWS, (3) WIRE CONNECTORS, (2) 8–32 X 1–1/4" SCREWS, NIPPLE, NUT AND FINIAL.

FIXTURE ASSEMBLY

1. ATTACH ONE END LINK OF THE CHAN TO LOWER LOOP AS SHOWN. DETERMINE THE LENGTH OF CHAIN REQUIRED TO HANG THE FIXTURE AT THE DESIRE HEIGHT, REMOVE OR ADD CHAIN AS DESIRED. ATTACH THE QUICK LINK TO ONE END LINK OF CHAIN AND ATTACH THE QUICK LINK TO THE UPPER CHAIN LOOP. REMOVE OR ADD CHAIN AS DESIRED AT THIS TIME. THREAD FIXTURE WIRE AND GROUND WIRE UP THROUGH EVERY OTHER LINK OF CHAIN.



TO SPREAD A LINK OF CHAIN

USE A PAIR OF PLIERS AND A SCREWDRIVER AS SHOWN ABOVE, BEING CAREFUL TO WRAP THE JAWS OF THE PLIERS WITH CLOTH TO PROTECT THE FINISH OF THE CHAIN.

****STOP** COMPLETE INSTALLATION INSTRUCTIONS ON NEXT PAGE BEFORE PROCEEDING.**

FINAL ASSEMBLY

1. RAISE A GLASS SHADE OVER EACH SOCKET, THEN SECURE WITH A METAL CAP AND A SOCKET RING.

2. INSTALL A 100 WATT MAX. TYPE "A" BULB (NOT INCLUDED) INTO EACH SOCKET.

3. ATTACH HANGING HOOKS TO BOTTOM OF METAL FRAME AS DESIRED.

4. RESTORE POWER. YOUR NEW FIXTURE IS NOW READY TO USE.



INSTALLATION INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

CAUTION

TO AVOID POSSIBLE ELECTRIC SHOCK, MAKE SURE THE ELECTRICITY IS SHUT OFF AT THE MAIN PANEL. IF YOU ARE REPLACING AN EXISTING FIXTURE, FIRST TURN THE FIXTURE OFF. NEXT, TURN THE WALL SWITCH OFF. FINALLY, GO TO THE MAIN FUSE OR BREAKER BOX IN YOUR HOME. TURN THE FUSE OR BREAKER TO THE OFF POSITION. SOME TYPES OF FUSES MUST BE UNSCREWED TO SHUT OFF THE POWER.

* ALL WIRING MUST BE DONE IN ACCORDANCE WITH NATIONAL AND LOCAL ELECTRIC CODES.
** IF YOU DO NOT HAVE ELECTRICAL WIRING EXPERIENCE, HAVE YOUR FIXTURE INSTALLED BY A QUALIFIED LICENSED ELECTRICIAN.
*** THIS FIXTURE IS INTENDED TO BE MOUNTED TO A UL LISTED OUTLET BOX.
**** DUE TO THE WEIGHT OF THIS FIXTURE, THE CROSSBAR MUST BE INSTALLED INDEPENDENT OF THE OUTLET BOX. THIS FIXTURE IS INTENDED TO BE MOUNTED TO A 2" x 4" CROSS BRACE (SHOWN ABOVE) CAPABLE OF SUPPORTING THE FIXTURE.

COMPLETE FIXTURE ASSEMBLY INSTRUCTIONS FIRST (SEE PREVIOUS PAGE).

1. SCREW THE SCREW COLLAR LOOP ONTO THE NIPPLE AND THEN SCREW THE NIPPLE INTO THE CROSS BAR AND SECURE WITH NUT ON TOP SIDE. NEXT, ATTACH THE CROSS BAR TO THE CEILING OUTLET BOX USING THE TWO SCREWS PROVIDED WITH THE OUTLET BOX. (NOTE: IF THE SCREWS WITH THE OUTLET BOX ARE TOO SHORT, USE THE (2) 8-32 x 1 1/4" SCREWS PROVIDED IN THE MOUNTING HARDWARE PACKAGE).
2. SLIDE 3" WOOD SCREWS THROUGH SLOTS IN CROSS BAR AND SCREW INTO 2" x 4" CROSS BRACE. NOTE: THE SCREWS INSTALLED IN STEP 1 MAY NEED TO BE REMOVED AND THE CROSSBAR TURNED TO ALLOW THE WOOD SCREWS TO LINE UP WITH THE CROSS BRACE.
3. SLIDE THE SCREW COLLAR NUT AND THEN THE CANOPY ONTO THE END OF THE CHAIN. THEN FASTEN THE END LINK OF CHAIN TO THE SCREW COLLAR LOOP.
4. LACE FIXTURE WIRE AND GROUND WIRE UP THROUGH EVERY OTHER LINK OF CHAIN.
5. INSERT THE FIXTURE WIRE AND THE GROUND WIRE UP THROUGH THE NIPPLE. CONNECT THE WHITE OR RIBBED FIXTURE WIRE TO THE WHITE SUPPLY WIRE IN THE OUTLET BOX USING THE TWIST-ON WIRE CONNECTORS PROVIDED. CONNECT THE BLACK OR SMOOTH FIXTURE WIRE TO THE BLACK SUPPLY WIRE IN THE SAME MANNER. INSTALL THE FIXTURE GROUND WIRE UNDER THE GREEN GROUND SCREW ON THE CROSSBAR THEN CONNECT THE FIXTURE GROUND WIRE TO THE SUPPLY GROUND WIRE IN THE OUTLET BOX USING THE TWIST-ON WIRE CONNECTOR PROVIDED.
6. TUCK THE WIRES CAREFULLY INSIDE THE OUTLET BOX. SPREAD THE ELECTRICAL SPLICES SO THAT THE BLACK WIRES ARE ON ONE SIDE OF THE OUTLET BOX AND THE WHITE WIRES ARE ON THE OTHER SIDE.
7. RAISE THE CANOPY TO THE CEILING AND SECURE IN PLACE WITH FINIAL.
8. SEE PREVIOUS PAGE FOR FINAL ASSEMBLY INSTRUCTIONS.